

Roomba TV Software Installation Guide for Apple TV






Table of Contents

1	iPla	yTV Installation	3
2	Sett	ing up IPTV Playlist	6
3	iPla	yTV Main Menu	12
	3.1	Channels	13
	3.2	Movies	16
	3.3	Shows	19
	3.4	TV Guide	22
	3.5	Favourites	23
	3.6	Settings	24
4	Con	tact Us	25




1 iPlayTV Installation

1. Turn on your Apple TV, then launch the App Store.




2. Go to the **Search** menu. Enter "**iPlayTV**" on the search bar, then hit **search**. When the iPlayTV app appears on the search result, select it then install the application.





3. Alternatively, you can go to a web browser then copy and search the following link: https://apps.apple.com/app/iplaytv/id1072226801


This will redirect you to the App Store where you can purchase and install iPlayTV on your device.




Note: As of this writing, the iPlayTV app costs \$5.99. The iPlayTV app is available for Apple TV 3rd gen or above.



4. After the installation process, click **Open** to launch the iPlayTV app.




5. When you launch the app for the first time, the iPlayTV **Add Playlist** screen will be displayed.





2 Setting up IPTV Playlist


1. Click Add Playlist to set up your IPTV M3U playlist.





- 2. There are three (3) ways to add the IPTV M3U playlist:
 - Remote Playlist File allows you to configure the M3U playlist that is hosted in a remote server
 - Local File allows you to upload the M3U playlist to the iPlayTV app
 - Xtream Server allows you to connect to the Xtream Server by entering the login details given to you by the Roomba TV service provider

We highly advise you to choose **Xtream Server** playlist type as this option provides you with additional features such as Electronic Program Guide (EPG) and playlist auto-update.






3. On a web browser, open your email service provider app, then check for the email with the subject "Your Roomba TV Service Subscription".




4. Get the following details contained in the email which you will need to manually enter into the iPlayTV app (i.e., Username, Password and Portal or Server URL).





Fill in the following fields on the iPlayTV app using the credentials provided to you via email.




- Enter a Playlist Name (e.g., Roomba TV Playlist).
- Enter the Server URL which is "http://live.roomba.tv".
- Enter your Username (e.g., Demo).
- > Enter your password.

You can also choose to modify the default settings of the following options:


- Channels Refresh
- EPG Refresh
- EPG Time shift



6. After you have entered your login details, click **Save** to continue.




7. Wait for the application to finish downloading its components. (i.e., Channels, Movies, and Shows). This may take a little time depending on your internet connection speed and the number of bouquets you have purchased in your Roomba TV subscription.






8. When the following screen appears, this indicates that your IPTV M3U playlist is created successfully. The number of Channels, Movies and TV Shows are also displayed. Select the playlist you created to start using the app.





3 iPlayTV Main Menu



iPlayTV consists of the following sections:

- Channels
- TV Guide

Movies

Favourites


Shows

Settings




3.1 Channels

This section provides you with all the available channels included in your subscription.




You may scroll to the left pane of the screen to browse all channels per category.










Example of a TV channel playing








To display the Electronic Program Guide (EPG), scroll to the left pane of the screen.


You can choose a channel that you would like to add to your favorites by selecting Add to favourites option. Channels that are added to favourites can be accessed in the Favourites section.






3.2 Movies

This section allows you to access all the available movies. Select a movie that you would like to watch.




You may scroll to the left pane of the screen to browse all movies per category.






If you would like to check for new movies released, you may access them on the **New movies** category.



After selecting a category, select a specific movie that you would like to watch.





You may choose to watch the trailer first or you may click the **Play** button to watch the movie.




Example of a movie playing






3.3 Shows

This section allows you to access all the available TV shows. Search a specific show that you would like to watch.



If you would like to check for new TV shows released, you may access them on the **New TV shows** category.





You may choose to watch the trailer first or you may click the **Play** button to select from the available episodes.



Choose from the available episodes of a TV show that you would like to watch.

	9-1-1	
Episode 1		
Episode 2		
Episode 3		
Episode 4		
Episode 5		
Episode 6		
Episode 7		
Episode 8		
Episode 9		
Episode 10		




Example of an episode of a TV show playing





3.4 TV Guide


The TV Guide section or also called as the Electronic Program Guide (EPG) enables you to view the scheduling information for past, current, and upcoming TV programs for various channels.





3.5 Favourites

This section contains the channel(s) or TV show(s) that you added to favourites. Select a favorited channel or TV show that you would like to watch.




Example of a favorited TV show playing





3.6 Settings

The Settings section enables you to configure the iPlayTV app settings. This section also displays the IPTV M3U playlist information (i.e., the number of Channels, Movies, and TV Shows).





4 Contact Us

For inquiries or concerns about your Roomba TV account, you may submit a support ticket to the link below:

https://clients.roomba.tv/clientarea.php